

# Operator's Manual

Firmware V6.21 and higher



SWISS  MADE



## Customer Support

Swan and its representatives maintain a fully trained staff of technical specialists around the world. For any technical question, contact your nearest Swan representative, or the manufacturer:

Swan Analytische Instrumente AG  
Studbachstrasse 13  
8340 Hinwil  
Switzerland

Internet: [www.swan.ch](http://www.swan.ch)  
E-mail: [support@swan.ch](mailto:support@swan.ch)

## Document Status

<b>Title:</b>	AMI Deltacon Power Operator's Manual	
<b>ID:</b>	A-96.250.451	
<b>Revision</b>	<b>Issue</b>	
00	Sept. 2009	Preliminary Edition
01	Nov. 2009	Update to FW Release 4.12
02	Jan. 2013	Improved troubleshooting
03	June 2020	Mainboard V2.6

© 2020, Swan Analytische Instrumente AG, Switzerland, all rights reserved.

The information contained in this document is subject to change without notice.

Table of Contents

<b>1. Safety Instructions</b>	<b>5</b>
1.1. Warning Notices	6
1.2. General Safety Regulations	8
1.3. Restriction for use	9
<b>2. Product Description</b>	<b>10</b>
2.1. Description of the System	10
2.2. Instrument Specification	14
2.3. Instrument Overview	16
<b>3. Installation</b>	<b>17</b>
3.1. Installation Checklist Monitors	17
3.2. Mounting of Instrument Panel	18
3.3. Connecting Sample Inlet and Outlet	18
3.3.1 Swagelok Fitting Stainless Steel at Sample Inlet	18
3.3.2 FEP Tube at Sample Outlet	19
3.4. Installation of Cation Exchanger	20
3.5. Electrical Connections	21
3.5.1 Connection Diagram	23
3.5.2 Power Supply	24
3.6. Input	25
3.7. Relay Contacts	25
3.7.1 Alarm Relay	25
3.7.2 Relay 1 and 2	26
3.8. Signal Outputs	28
3.8.1 Signal Output 1 and 2 (current outputs)	28
3.9. Interface Options	28
3.9.1 Signal Output 3	29
3.9.2 Profibus, Modbus Interface	29
3.9.3 HART Interface	30
3.9.4 USB Interface	30
<b>4. Instrument Setup</b>	<b>31</b>
4.1. Establish sample flow	31
4.2. Programming	31
<b>5. Operation</b>	<b>33</b>
5.1. Keys	33
5.2. Display	33
5.3. Software Structure	35
5.4. Changing Parameters and values	36

<b>6. Maintenance</b> .....	<b>37</b>
6.1. Maintenance Schedule .....	37
6.2. Stop of Operation for Maintenance .....	37
6.3. Maintenance of the Sensor .....	38
6.3.1 Remove the Sensor from the Flow Cell .....	38
6.3.2 Install the Sensor into the Flow Cell .....	38
6.4. Changing the Cation Exchanger .....	39
6.5. Changing the inlet filter .....	42
6.6. Tube Connections .....	43
6.7. Replace the Deaeration Tubes .....	44
6.7.1 Exchange deaeration tube of cation exchanger bottle .....	45
6.7.2 Exchange deaeration tube of pre-rinse bottle .....	45
6.8. Longer Stop of Operation .....	46
<b>7. Troubleshooting</b> .....	<b>47</b>
7.1. Error List .....	48
7.2. Replacing Fuses .....	52
<b>8. Program Overview</b> .....	<b>53</b>
8.1. Messages (Main Menu 1) .....	53
8.2. Diagnostics (Main Menu 2) .....	54
8.3. Maintenance (Main Menu 3) .....	55
8.4. Operation (Main Menu 4) .....	55
8.5. Installation (Main Menu 5) .....	56
<b>9. Program List and Explanations</b> .....	<b>58</b>
1 Messages .....	58
2 Diagnostics .....	58
3 Maintenance .....	59
4 Operation .....	60
5 Installation .....	62
<b>10. Material Safety Data Sheets</b> .....	<b>78</b>
10.1. Swan Cation Exchanger Resin .....	78
<b>11. Default Values</b> .....	<b>79</b>
<b>12. Index</b> .....	<b>82</b>
<b>13. Notes</b> .....	<b>84</b>

---

# AMI Deltacon Power– Operator’s Manual

---

This document describes the main steps for instrument setup, operation and maintenance.

## 1. Safety Instructions

<b>General</b>	<p>The instructions included in this section explain the potential risks associated with instrument operation and provide important safety practices designed to minimize these risks.</p> <p>If you carefully follow the information contained in this section, you can protect yourself from hazards and create a safer work environment.</p> <p>More safety instructions are given throughout this manual, at the respective locations where observation is most important. Strictly follow all safety instructions in this publication.</p>
<b>Target audience</b>	<p>Operator: Qualified person who uses the equipment for its intended purpose.</p> <p>Instrument operation requires thorough knowledge of applications, instrument functions and software program as well as all applicable safety rules and regulations.</p>
<b>OM Location</b>	<p>Keep the AMI Operator’s Manual in proximity of the instrument.</p>
<b>Qualification, Training</b>	<p>To be qualified for instrument installation and operation, you must:</p> <ul style="list-style-type: none"><li>♦ read and understand the instructions in this manual as well as the Material Safety Data Sheets.</li><li>♦ know the relevant safety rules and regulations.</li></ul>

## 1.1. Warning Notices

The symbols used for safety-related notices have the following meaning:



### **DANGER**

Your life or physical wellbeing are in serious danger if such warnings are ignored.

- ◆ Follow the prevention instructions carefully.



### **WARNING**

Severe injuries or damage to the equipment can occur if such warnings are ignored.

- ◆ Follow the prevention instructions carefully.



### **CAUTION**

Damage to the equipment, minor injury, malfunctions or incorrect process values can be the consequence if such warnings are ignored.

- ◆ Follow the prevention instructions carefully.

### **Mandatory Signs**

The mandatory signs in this manual have the following meaning:



Safety goggles



Safety gloves

**Warning Signs**    The warning signs in this manual have the following meaning:



Electrical shock hazard



Corrosive



Harmful to health



Flammable



Warning general



Attention general

## 1.2. General Safety Regulations

### Legal Requirements

The user is responsible for proper system operation. All precautions must be followed to ensure safe operation of the instrument.

### Spare Parts and Disposables

Use only official SWAN spare parts and disposables. If other parts are used during the normal warranty period, the manufacturer's warranty is voided.

### Modifications

Modifications and instrument upgrades shall only be carried out by an authorized Service Technician. SWAN will not accept responsibility for any claim resulting from unauthorized modification or alteration.

### WARNING

#### Electrical Shock Hazard



If proper operation is no longer possible, the instrument must be disconnected from all power lines, and measures must be taken to prevent inadvertent operation.

- ◆ To prevent from electrical shock, always make sure that the ground wire is connected.
- ◆ Service shall be performed by authorized personnel only.
- ◆ Whenever electronic service is required, disconnect instrument power and power of devices connected to.
  - relay 1,
  - relay 2,
  - alarm relay

### WARNING



For safe instrument installation and operation you must read and understand the instructions in this manual.

### WARNING



Only SWAN trained and authorized personnel shall perform the tasks described in this document.



### 1.3. Restriction for use

The AMI Deltacon Power is designed for determination of:

- ♦ specific (total) conductivity
- ♦ cation (acid) conductivity after the cation exchanger

in power plant water.

It calculates the pH value and the concentration of the alkaline substance (NH<sub>3</sub>, morpholine, etc.) if an alkaline substance is present in the water.

It is not suitable for pH determination in high purity water before alkalization agent addition.

#### Conditions for pH calculation:

- ♦ only 1 alkalization agent in the sample
- ♦ the contamination is mostly NaCl
- ♦ phosphate concentration is < 0.5 ppm
- ♦ pH value is > 7.5, and < 11.5
- ♦ if pH value is < 8, the concentration of contaminant must be small compared to the concentration of the alkalization agent

No sand. No oil.

The sample must not contain any particles, which may block the flow cell. Sufficient sample flow is coercive for the correct function of the instrument.



#### WARNING

For safe instrument installation and operation you must read and understand the instructions in this manual, as well as the Material Safety Data Sheets (MSDS)

- ♦ Cation Exchange Resin

#### Download MSDS

The current Material Safety Data Sheets (MSDS) for the below listed Reagents are available for downloading at [www.swan.ch](http://www.swan.ch).

Product name:	Cation Exchange Resin
Catalogue number:	A-82.841.030, A-82.841.031 and A-82.841.035

## 2. Product Description


### 2.1. Description of the System

<b>Application Range</b>	The AMI Deltacon Power is a complete monitoring system for the automatic, continuous measurement of the total (specific) conductivity before a cation exchanger and the cation (acid) conductivity after a cation exchanger. Based on difference conductivity measurement, the pH of the sample can be calculated.
<b>Special Features</b>	<ul style="list-style-type: none"><li>◆ Temperature compensation curves for conductivity measurement:<ul style="list-style-type: none"><li>– Strong acids (HCl)</li><li>– Strong bases (NaOH)</li><li>– Ammonia</li><li>– Morpholine</li><li>– Ethanolamines (ETA)</li></ul></li><li>◆ Flow monitoring</li><li>◆ Surveillance of resin exhaustion.</li><li>◆ Calculation of pH according to the (VGB 450L, edition 2006).</li><li>◆ Calculates the concentration of an alkaline substance present in the water.</li></ul>
<b>Signal Outputs</b>	<p>Two signal outputs programmable for measured values (freely scalable, linear, bilinear, log) or as continuous control output (control parameters programmable).</p> <p>Current loop:           0/4–20 mA Maximal burden:       510 Ω</p> <p>Third signal output available as an option. The third signal output can be operated as a current source or as a current sink (selectable via switch).</p>
<b>Relays</b>	<p>Two potential-free contacts programmable as limit switches for measuring values, controllers or timer for system cleaning with automatic hold function. Both contacts can be set as normally open or normally closed with a jumper.</p> <p>Maximum load: 1 A/250 VAC</p>

<b>Alarm Relay</b>	<p>One potential free contact alternatively:</p> <ul style="list-style-type: none"><li>◆ Open during normal operation, closed on error and loss of power.</li><li>◆ Closed during normal operation, open on error and loss of power.</li></ul> <p>Summary alarm indication for programmable alarm values and instrument faults.</p>
<b>Input</b>	<p>For potential-free contact to freeze the measuring value or to interrupt control in automated installations (<i>hold</i> function or <i>remote-off</i>).</p>
<b>Communication interface (optional)</b>	<ul style="list-style-type: none"><li>◆ USB Interface for logger download</li><li>◆ Third signal output (can be used in parallel to the USB interface)</li><li>◆ RS485 with Fieldbus protocol Modbus or Profibus DP</li><li>◆ HART interface</li></ul>
<b>Safety Features</b>	<p>No data loss after power failure. All data is saved in non-volatile memory.</p> <p>Over voltage protection of in- and outputs.</p> <p>Galvanic separation of measuring inputs and signal outputs.</p>
<b>Measuring principle</b>	<p>When a voltage is set between two electrodes in an electrolyte solution, the result is an electric field which exerts force on the charged ions: the positively charged cations move towards the negative electrode (cathode) and the negatively charged anions towards the positive electrode (anode). The ions, by way of capture or release of electrons at the electrodes, are discharged and so a current <math>I</math> flows through this cycle and the Ohms law <math>V = I \times R</math> applies. From the total resistance <math>R</math> of the current loop, only the resistance of the electrolyte solution, respectively its conductivity <math>1/R</math>, is of interest.</p> <p>The cell constant of the sensor is determined by the manufacturer and is printed on the sensor label. If the cell constant has been programmed in the transmitter, the instrument measures correctly. No calibration needs to be done, the sensor is factory calibrated. Measuring unit is <math>\mu\text{S}/\text{cm}</math> or <math>\mu\text{S}/\text{m}</math>.</p>
<b>Specific Conductivity</b>	<p>Conductivity from all ions in the sample, mainly the alkalization agent. The contribution of impurities is masked by the alkalization agent.</p>
<b>Cation Conductivity (Acid Conductivity)</b>	<p>The alkalization agent is removed in the cation column. All cationic ions are exchanged with <math>\text{H}^+</math>, all anionic impurities (ions with negative charge) pass through the column unchanged.</p>

<b>Temperature compensation</b>	<p>The mobility of ions in water increase with higher temperature which enlarges the conductivity. Therefore, the temperature is measured simultaneous by an integrated Pt1000 temperature sensor and the conductivity is compensated to 25 °C. Several temperature compensation curves, designed for different water compositions, can be chosen.</p> <p>After cation exchanger (cation conductivity), the temperature compensation curve strong acids has to be set.</p> <p>For more information see: <b>Influence of Temperature on Electrical Conductivity, PPCChem (2012).</b></p>
<b>Standard Temperature</b>	<p>The displayed conductivity value is compensated to 25 °C standard temperature.</p>
<b>Operation</b>	<p>The sample flows via the sample inlet [G] through the flow regulating valve [C], where the flow rate can be adjusted, into the flow cell block [B].</p> <p>With the first conductivity sensor [A] the specific conductivity of the sample is measured. Then the sample is led through the cation exchanger bottle [M] where all alkalization agent is eliminated. Afterwards the cation conductivity of the sample is measured with the second conductivity sensor [H].</p> <p>The sample leaves the measuring cell via flow meter and the sample collector [J] and flows into the pressure-free sample outlet.</p> <p>The temperature is measured with the temperature sensors integrated in the conductivity sensors.</p>
<b>Pre-rinse Option</b>	<p>The AMI Deltacon Power with pre-rinse option allows fast replacement of the cation exchanger because the resin is pre-rinsed. Pre-rinsing has the effect to remove disturbing contaminations contained in the resin, which may cause incorrect measuring values. The de-aeration of the resin vessel is done automatically.</p> <p>If the pre-rinse option is installed, the sample flows via flow meter through the pre-rinse inlet [D] into the second cation exchanger bottle [F] and from there via pre-rinse outlet [E] through the sample collector [J] into the waste funnel.</p> <p>The cation exchanger bottles are vented via two small tubes which are connected to the flanges [K] and [L].</p>
<b>Correction or calibration</b>	<p>Not necessary.</p> <p>Auto zero is done automatically each day at 0:30 at night.</p>

**Fluidics overview**




- |   |   |
|---|---|
| <b>A</b> First conductivity sensor          | <b>I</b> Flow meter                             |
| <b>B</b> Flow cell block                    | <b>J</b> Sample collector                       |
| <b>C</b> Flow regulating valve              | <b>K</b> Deaeration tube cation exchange bottle |
| <b>D</b> Pre-rinse inlet                    | <b>L</b> Deaeration tube pre-rinse bottle       |
| <b>E</b> Pre-rinse outlet                   | <b>M</b> Active cation exchange bottle          |
| <b>F</b> Pre-rinsed cation exchanger bottle | <b>N</b> Sample outlet                          |
| <b>G</b> Sample inlet                       |   |
| <b>H</b> Second conductivity sensor         |   |

## 2.2. Instrument Specification

<b>Power Supply</b>	AC variant:	100–240 VAC (±10%) 50/60 Hz (±5%)
	DC variant:	10–36 VDC
	Power consumption:	max. 35 VA
<b>Sample requirements</b>	Flow rate:	5–20 l/h
	Temperature:	up to 50 °C
	Inlet pressure:	up to 2 bar
	Outlet pressure:	pressure free
<b>On-site requirements</b>	The analyzer site must permit connections to:	
	Sample inlet:	Swagelok 1/4" adapter for stainless steel tube
	Sample outlet:	G ½" adapter for flexible tube 15 x 20 mm
<b>Measuring range</b>	Measuring range	Resolution
	0.055 to 0.999 µS/cm	0.001 µS/cm
	1.00 to 9.99 µS/cm	0.01 µS/cm
	10.0 to 99.9 µS/cm	0.1 µS/cm
	100 to 1000 µS/cm	1 µS/cm
	Automatic range switching. Accuracy: ±1% of measured value or ±1 digit (whichever is greater). Ranges and accuracy valid for a cell constant of 0.0415 cm <sup>-1</sup> (Swansensor UP-Con1000).	
<b>Transmitter specifications</b>	Housing:	Aluminium with a protection degree of IP 66 / NEMA 4X
	Ambient temperature:	-10 to +50 °C
	Storage and transport:	-30 to +85 °C
	Humidity:	10–90% rel., non-condensing
	Display:	backlit LCD, 75 x 45 mm

<b>Dimensions</b>	Panel:	stainless steel
	Dimensions:	280 x 850 x 200 mm
	Screws:	5 mm or 6 mm diameter
	Weight:	10 kg



### 2.3. Instrument Overview



- |                                       |                                      |
|---------------------------------------|--------------------------------------|
| <b>A</b> Panel                        | <b>G</b> Flow regulating valve       |
| <b>B</b> Transmitter                  | <b>H</b> Sample collector            |
| <b>C</b> Specific conductivity sensor | <b>I</b> Active cation exchanger     |
| <b>D</b> Cation conductivity sensor   | <b>J</b> Pre-rinsed cation exchanger |
| <b>E</b> Flow cell                    | <b>K</b> Sample inlet                |
| <b>F</b> Flow meter                   | <b>L</b> Sample outlet               |



## 3. Installation

### 3.1. Installation Checklist Monitors

<b>On-site requirements</b>	AC variant: 100–240 VAC ( $\pm 10\%$ ), 50/60 Hz ( $\pm 5\%$ ) DC variant: 10–36 VDC Power consumption: 35 VA maximum Protective earth connection required Sample line with sufficient sample flow and pressure (see <a href="#">Instrument Specification, p. 14</a> ).
<b>Installation</b>	<ul style="list-style-type: none"> <li>◆ Mount the instrument in vertical position.</li> <li>◆ Display should be at eye level.</li> <li>◆ Connect sample inlet and outlet.</li> <li>◆ Monitor: Sensors are already mounted.</li> <li>◆ Single flow cell: Mount sensors (see <a href="#">Maintenance of the Sensor, p. 38</a>), and connect cables (see <a href="#">Connection Diagram, p. 23</a>).</li> </ul>
<b>Electrical Wiring</b>	<ul style="list-style-type: none"> <li>◆ Connect all external devices like limit switches, current loops and pumps (see <a href="#">Connection Diagram, p. 23</a>).</li> <li>◆ Connect power cord; do not switch on power yet!</li> </ul>
<b>Cation exchanger</b>	<ul style="list-style-type: none"> <li>◆ Fill up cation exchanger bottle with high purity water. Remove the empty bottle and install the cation exchanger bottle.</li> <li>◆ With pre-rinse set-up, install a cation exchanger bottle to the second flange.</li> </ul>
<b>Power-up</b>	<ul style="list-style-type: none"> <li>◆ Open sample flow and wait until flow cell is completely filled.</li> <li>◆ The cation exchanger bottle is deaerated automatically.</li> <li>◆ Switch on power. Adjust sample flow.</li> </ul>
<b>Instrument set-up</b>	<ul style="list-style-type: none"> <li>◆ Program all sensor parameters (see <a href="#">Sensor parameters, p. 31</a>).</li> <li>◆ If required activate calculations (see <a href="#">Calculations, p. 32</a>).</li> <li>◆ Program all parameters for external devices (interface, recorders, etc.).</li> <li>◆ Program all parameters for instrument operation (limits, alarms).</li> <li>◆ Program display screens.</li> </ul>
<b>Run-in period</b>	Let the instrument run continuously for 1 h. This is valid for rinsed cation exchanger resin (nuclear grade) delivered by Swan. If you do not use rinsed cation exchanger resin, the run-in period may be much longer.



## 3.2. Mounting of Instrument Panel

The first part of this chapter describes the preparing and placing of the system for use.

- ◆ The instrument must only be installed by trained personnel.
- ◆ Mount the instrument in vertical position.
- ◆ For ease of operation mount it so that the display is at eye level.
- ◆ For the installation a kit containing the following installation material is available:
  - 4 Screws 6x60 mm
  - 4 Dowels
  - 4 Washers 6.4/12 mm

### Mounting requirements

The instrument is only intended for indoor installation. For dimensions see [Dimensions](#), p. 15.

## 3.3. Connecting Sample Inlet and Outlet

### 3.3.1 Swagelok Fitting Stainless Steel at Sample Inlet


#### Preparation

Cut the tube to length and deburr it. The tube must be straight and free from blemishes for approximately 1,5 x tube diameter from the end.

Lubrication with lubricating oil, MoS<sub>2</sub>, Teflon etc. is recommended for the assembly and reassembly of bigger sized unions (thread, compression cone).

#### Installation


- 1 Insert the compression ferrule [C] and the compression cone [D] into the union nut [B].
- 2 Screw on the union nut onto the body, do not tighten it.
- 3 Push the stainless steel pipe through the union nut as far as it reaches the stop of the body.
- 4 Mark the union nut at 6 o'clock position.
- 5 While holding the fitting body steady, tighten the nut union 1¼ rotation using an open ended spanner.



- |                                      |                                      |
|--------------------------------------|--------------------------------------|
| <b>A</b> <i>Stainless steel tube</i> | <b>D</b> <i>Compression cone</i>     |
| <b>B</b> <i>Union nut</i>            | <b>E</b> <i>Body</i>                 |
| <b>C</b> <i>Compression ferrule</i>  | <b>F</b> <i>Tightened connection</i> |

### 3.3.2 FEP Tube at Sample Outlet

1/2" Tube at waste funnel.




Connect the 1/2" tube [C] to the hose nozzle [B] and place it into a drain with atmospheric pressure.



### 3.4. Installation of Cation Exchanger

#### Cation exchanger bottle

The bottle containing the cation exchanger is delivered separately. For transport, an empty bottle is installed into the bottle holder.



#### Install cation exchanger bottle

Install the cation exchanger bottle as follows:

- 1 Unscrew and remove the empty bottle [E] from the bottle holder [B].
- 2 Fill high purity water into the cation exchanger bottle [C], until the water level in the bottle reaches the beginning of the thread.
- 3 Carefully, without spilling water, push the cation exchanger bottle over the inlet filter holder [D] into the bottle holder [B].
- 4 Screw the cation exchanger bottle into the bottle holder.  
**⚠ Do not tighten the bottle too firmly, this could damage the gasket.**

#### Pre-rinse set-up

If you have a pre-rinse set-up, proceed according to “**Install cation exchanger bottle**” to install the second cation exchanger bottle.

### 3.5. Electrical Connections




#### WARNING

##### Electrical hazard

- ◆ Always turn off power before manipulating electric parts.
- ◆ Grounding requirements: Only operate the instrument from a power outlet which has a ground connection.
- ◆ Make sure the power specification of the instrument corresponds to the power on site.

#### Cable thicknesses

In order to comply with IP66, use the following cable thicknesses:



**A** PG 11 cable gland: cable  $\varnothing_{outer}$  5–10 mm

**B** PG 7 cable gland: cable  $\varnothing_{outer}$  3–6.5 mm

**C** PG 9 cable gland: cable  $\varnothing_{outer}$  4–8 mm

**Note:** Protect unused cable glands

#### Wire

- ◆ For power and relays: Use max. 1.5 mm<sup>2</sup> / AWG 14 stranded wire with end sleeves.
- ◆ For signal outputs and input: Use 0.25 mm<sup>2</sup> / AWG 23 stranded wire with end sleeves.





**WARNING**

**External voltage**

External supplied devices connected to relay 1 or 2 or to the alarm relay can cause electrical shocks.

- ◆ Make sure that the devices connected to the following contacts are disconnected from the power before resuming installation.
  - relay 1
  - relay 2
  - alarm relay



**WARNING**


To prevent from electrical shock, do not connect the instrument to the power unless the ground wire (PE) is connected.



**WARNING**

The mains of the AMI transmitter must be secured by a main switch and appropriate fuse or circuit breaker.

### 3.5.1 Connection Diagram



DELTACON

#### CAUTION



Use only the terminals shown in this diagram, and only for the mentioned purpose. Use of any other terminals will cause short circuits with possible corresponding consequences to material and personnel.


### 3.5.2 Power Supply



#### WARNING

#### Electrical shock hazard

Installation and maintenance of electrical parts must be performed by professionals. Always turn off power before manipulating electric parts.



- A Power supply connector
- B Neutral conductor, Terminal 2
- C Phase conductor, Terminal 1
- D Protective earth PE

**Note:** The protective earth wire (ground) has to be connected to the grounding terminal.

#### Installation requirements

The installation must meet the following requirements.

- ◆ Mains cable to comply with standards IEC 60227 or IEC 60245; flammable rating FV1
- ◆ Mains equipped with an external switch or circuit-breaker
  - near the instrument
  - easily accessible to the operator
  - marked as interrupter for AMI Deltacon Power



### 3.6. Input

**Note:** Use only potential-free (dry) contacts.

The total resistance (sum of cable resistance and resistance of the relay contact) must be less than 50 Ω.

Terminals 16/42

For programming see [Program List and Explanations, p. 58](#).

### 3.7. Relay Contacts

#### 3.7.1 Alarm Relay

**Note:** Max. load 1 A / 250 VAC

Alarm output for system errors.

Error codes see [Troubleshooting, p. 47](#).

**Note:** With certain alarms and certain settings of the AMI transmitter the alarm relay does not switch. The error, however, is shown on the display.

	Terminals	Description	Relay connection
<b>NC</b> <sup>1)</sup> Normally Closed	10/11	Active (opened) during normal operation. Inactive (closed) on error and loss of power.	
<b>NO</b> Normally Open	12/11	Active (closed) during normal operation. Inactive (opened) on error and loss of power.	

1) usual use


### 3.7.2 Relay 1 and 2

**Note:** Max. load 1 A/250 VAC

Relay 1 and 2 can be configured as normally open or as normally closed. Standard for both relays is normally open. To configure a Relay as normally closed, set the jumper in the upper position.

**Note:** Some error codes and the instrument status may influence the status of the relays described below.

Relay config.	Terminals	Jumper pos.	Description	Relay configuration
Normally Open	6/7: Relay 1 8/9: Relay 2		Inactive (opened) during normal operation and loss of power. Active (closed) when a programmed function is executed.	
Normally Closed	6/7: Relay 1 8/9: Relay 2		Inactive (closed) during normal operation and loss of power. Active (opened) when a programmed function is executed.	



- A** Jumper set as normally open (standard setting)
- B** Jumper set as normally closed

For programming see [Program List and Explanations, p. 58](#), Menu Installation



**CAUTION**

**Risk of damage of the relays in the AMI Transmitter due to heavy inductive load.**


Heavy inductive or directly controlled loads (solenoid valves, dosing pumps) may destroy the relay contacts.

- ♦ To switch inductive loads > 0.1 A use an AMI relay box available as an option or suitable external power relays.

**Inductive load**

Small inductive loads (max 0.1 A) as for example the coil of a power relay can be switched directly. To avoid noise voltage in the AMI Transmitter it is mandatory to connect a snubber circuit in parallel to the load.


A snubber circuit is not necessary if an AMI relaybox is used.



- A** AC or DC power supply
- B** AMI Transmitter
- C** External power relay
- D** Snubber
- E** Power relay coil

**Resistive load**


Resistive loads (max. 1 A) and control signals for PLC, impulse pumps and so on can be connected without further measures



- A** AMI Transmitter
- B** PLC or controlled pulse pump
- C** Logic

**Actuators**

Actuators, like motor valves, are using both relays: One relay contact is used for opening, the other for closing the valve, i.e. with the 2 relay contacts available, only one motor valve can be controlled. Motors with loads bigger than 0.1 A must be controlled via external power relays or an AMI relay box.



- A** AC or DC power supply
- B** AMI Transmitter
- C** Actuator

### 3.8. Signal Outputs

#### 3.8.1 Signal Output 1 and 2 (current outputs)

**Note:** Max. burden 510  $\Omega$ .


If signals are sent to two different receivers, use signal isolator (loop isolator).

Signal output 1: Terminals 14 (+) and 13 (-)

Signal output 2: Terminals 15 (+) and 13 (-)

For programming see [Program List and Explanations, p. 58](#), menu Installation.

### 3.9. Interface Options



The slot for interfaces can be used to expand the functionality of the AMI instrument with either:


- ◆ Third signal output
- ◆ a Profibus or Modbus connection
- ◆ a HART connection
- ◆ an USB Interface

### 3.9.1 Signal Output 3

Terminals 38 (+) and 37 (-).

Requires the additional board for the third signal output 0/4–20 mA. The third signal output can be operated as a current source or as a current sink (switchable via switch [A]). For detailed information see the corresponding installation instruction.

**Note:** Max. burden 510 Ω.



Third signal output 0/4 - 20 mA PCB


**A** Operating mode selector switch

### 3.9.2 Profibus, Modbus Interface

Terminal 37 PB, Terminal 38 PA

To connect several instruments by means of a network or to configure a PROFIBUS DP connection, consult the PROFIBUS manual. Use appropriate network cable.

**Note:** The switch must be ON, if only one instrument is installed, or on the last instrument in the bus.




Profibus, Modbus Interface PCB (RS 485)

**A** On - OFF switch

### 3.9.3 HART Interface

Terminals 38 (+) and 37 (-).

The HART interface PCB allows for communication via the HART protocol. For detailed information, consult the HART manual.




HART Interface PCB

### 3.9.4 USB Interface

The USB Interface is used to store Logger data and for Firmware upload. For detailed information see the corresponding installation instruction.

The optional third signal output 0/4 – 20 mA PCB [B] can be plugged onto the USB interface and used in parallel.



USB Interface

**A** USB interface PCB

**B** Third signal output 0/4 - 20 mA PCB

## 4. Instrument Setup

After the analyzer is installed according to the previous instructions, connect the power cord. Do not switch on power, yet!

### 4.1. Establish sample flow

- 1 Open flow regulating valve, see [Fluidics overview, p. 13](#).
- 2 Wait until the flow cell has been completely filled.
- 3 Switch on power.
- 4 Adjust the sample flow to 5 - 10 l/h.
- 5 Let the instrument run-in for 1 h.  
⇒ *This recommendation is valid for rinsed cation exchanger resin (nuclear grade) delivered by Swan.*

**Note:** *Not rinsed cation exchanger resin from other suppliers can take a run-in period of several hours to several days.*

### 4.2. Programming

#### Sensor parameters

Program all sensor parameters in Menu Installation-Sensors: menu 5.1.2.1.1 for sensor 1 and menu 5.1.2.2.1 for sensor 2.

The sensor characteristics are printed on the label of each sensor.

87-344.203	UP-Con1000SL	Sensor typ
SW-xx-xx-xx	ZK = 0.0417	Cell constant
SWAN AG	DT = 0.06 °C	Temperature correction

Enter for each sensor separately the:

- ♦ Cell constant [ $\text{cm}^{-1}$ ]
- ♦ Temperature correction [ $^{\circ}\text{C}$ ]
- ♦ Cable length [m]

**Note:** *Set the cable length to 0.0 m if the sensors are installed in the flow cell on the AMI monitor.*

- ♦ Temperature compensation: The default setting for sensor 1 (specific conductivity) is ammonia.


---

<b>Calculations</b>	Menu 5.1.1.1 Set <Calculations> to “Yes” if you want to have pH and alkalization agent calculated and displayed.
<b>Measuring unit</b>	Menu 5.1.1.2 Set the <Measuring unit> according to your requirements: <ul style="list-style-type: none"><li>◆ <math>\mu\text{S}/\text{cm}</math></li><li>◆ <math>\mu\text{S}/\text{m}</math></li></ul>
<b>Monitoring of cation exchanger resin</b>	Menu 5.1.1.3 Set <Monitoring of resin> to “Yes” if you want to monitor the capacity of the cation exchanger resin.
<b>Display</b>	Menu 4.4.1, Screen 1 Menu 4.4.2, Screen 2 Program display screens according to your requirements, see program list and explanations <a href="#">4.4 Display, p. 61</a> .
<b>External devices</b>	Program all parameters for external devices (interface, recorders, etc.) See program list and explanations <a href="#">5.2 Signal Outputs, p. 63</a> and <a href="#">4.2 Relay Contacts, p. 60</a> .
<b>Limits Alarms</b>	Program all parameters for instrument operation (limits, alarms). See program list and explanations <a href="#">4.2 Relay Contacts, p. 60</a> .




## 5. Operation

### 5.1. Keys




- A** to exit a menu or command (rejecting any changes) to move back to the previous menu level
- B** to move DOWN in a menu list and to decrease digits
- C** to move UP in a menu list and to increase digits to switch between display1 and 2
- D** to open a selected sub-menu to accept an entry

#### Program Access, Exit




### 5.2. Display

#### Example of Display 1



Example of  
Display 2



- A** RUN normal operation
- HOLD input closed or cal delay: Instrument on hold (shows status of signal outputs).
- OFF input closed: control/limit is interrupted (shows status of signal outputs).
- B** ERROR Error Fatal Error
- C** Remaining cation exchanger resin in % (if monitoring of resin = yes)
- D** Keys locked, transmitter control via Profibus
- E** Time
- F** F<sub>1</sub> Process values Display 1; F<sub>2</sub> Process values Display 2
- G** Sample temperature 2
- H** Sample temperature 1
- I** Sample flow in l/h
- K** Relay status

Relay status, symbols

- upper/lower limit not yet reached
- upper/lower limit reached
- control upw./downw. no action
- control upw./downw. active, dark bar indicates control intensity
- motor valve closed
- motor valve: open, dark bar indicates approx. position
- timer
- timer: timing active (hand rotating)

### 5.3. Software Structure

<b>Main Menu</b>	1
Messages	▶
Diagnostics	▶
Maintenance	▶
Operation	▶
Installation	▶

<b>Messages</b>	1.1
Pending Errors	▶
Maintenance List	▶
Message List	▶

<b>Diagnostics</b>	2.1
Identification	▶
Sensors	▶
Sample	▶
I/O State	▶
Interface	▶

<b>Maintenance</b>	3.1
Simulation	▶
Set Time	23.09.06 16:30:00

<b>Operation</b>	4.1
Sensors	▶
Relay Contacts	▶
Logger	▶
Display	▶

<b>Installation</b>	5.1
Sensors	▶
Signal Outputs	▶
Relay Contacts	▶
Miscellaneous	▶
Interface	▶

#### Menu **Messages 1**

Reveals pending errors as well as an event history (time and state of events that have occurred at an earlier point of time). It contains user relevant data.

#### Menu **Diagnostics 2**

Provides user relevant instrument and sample data.

#### Menu **Maintenance 3**

For instrument calibration, relay and signal output simulation, and to set the instrument time. It is used by the service personnel.

#### Menu **Operation 4**

User relevant parameters that might need to be modified during daily routine. Normally password protected and used by the process-operator. Subset of menu 5 - Installation, but process-related.


#### Menu **Installation 5**

For initial instrument set up by SWAN authorized person, to set all instrument parameters. Can be protected by means of password.

## 5.4. Changing Parameters and values


### Changing parameters

The following example shows how to change the logger interval:



Logger 4.4.1  
Log interval 30 min  
Clear logger no


- 1 Select the parameter you want to change.
- 2 Press [Enter]



Logger 4.1.3  
Log inter Interval. ↓  
Clear log 5 min  
10 min  
30 min  
1 Hour

- 3 Press [▲] or [▼] key to highlight the required parameter.
- 4 Press [Enter] to confirm the selection or [Exit] to keep the previous parameter).


⇒ *The selected parameter is highlighted (but not saved yet).*



Logger 4.1.3  
Log interval 10 min  
Clear logger no

- 5 Press [Exit].

⇒ *Yes is highlighted.*




Logger 4.1.3  
Log inter Save ?  
Clear log Yes  
No

- 6 Press [Enter] to save the new parameter.


⇒ *The system reboots, the new parameter is set.*

### Changing values



Cond. 1 (sc) 5.3.1.1.1  
Alarm High 3000 μS  
Alarm Low 0.000 μS  
Hysteresis 10.0 μS  
Delay 5 Sec

- 1 Select the value you want to change.
- 2 Press [Enter].
- 3 Set required value with [▲] or [▼] key.



Cond. 1 (sc) 5.3.1.1.1  
Alarm High 2500 μS  
Alarm Low 0.000 μS  
Hysteresis 10.0 μS  
Delay 5 Sec

- 4 Press [Enter] to confirm the new value.
- 5 Press [Exit].  
⇒ *Yes is highlighted.*
- 6 Press [Enter] to save the new value.

## 6. Maintenance

### 6.1. Maintenance Schedule

<b>Monthly</b>	<ul style="list-style-type: none"><li>◆ Check sample flow.</li><li>◆ If the monitoring of resin has been switched off: Check cation exchanger resin. The resin color changes to red/orange if exhausted.</li></ul>
<b>If required</b>	<ul style="list-style-type: none"><li>◆ Clean conductivity sensors</li><li>◆ Replace filter</li><li>◆ Replace deaeration tubes.</li></ul>

**Reagent consumption** A 1 l resin bottle, delivered by Swan lasts at 1 ppm alkalization agent (pH 9.4).


- ◆ for 4 months at sample flow 10 l/h,
- ◆ respectively 5 months at sample flow 5 l/h

### 6.2. Stop of Operation for Maintenance

- 1 Stop sample flow.
- 2 Shut off power of the instrument.



### 6.3. Maintenance of the Sensor



#### 6.3.1 Remove the Sensor from the Flow Cell

The sensors are fixed in the flow cell with a slot lock system. To remove the sensor from the flow cell proceed as follows:

- 1 Press the locking pin [B] down.
- 2 Turn the locking screw [C] with a 5 mm allen key counterclockwise 180°.  
⇒*The locking pin remains down.*
- 3 Remove the sensor.

**Cleaning** If the sensor is slightly contaminated, clean it with soapy water and a pipe cleaner. If the sensor is strongly contaminated, dip the tip of the sensor into 5% hydrochloric acid for a short time.


#### 6.3.2 Install the Sensor into the Flow Cell

- 1 Make sure that the locking mechanism is in unlocked position (locking screw in position [C] and locking pin in position [B]).
- 2 Put the sensor into the flow cell with the alignment marks [E] in line.
- 3 Turn the locking screw with a 5 mm allen key clockwise 180°.  
⇒*The locking pin moves up in lock position.*

## 6.4. Changing the Cation Exchanger

The resin of the ion exchanger changes its color from dark violet to brown if the capacity is exhausted. The resin should be changed before no violet resin is left or the cation conductivity rises above the normal value. At a concentration of 1 ppm alkalization agent, one resin filling will last for roughly 4 months if sample flow is 10 l/h, or 5 months if sample flow is 5 l/h.

without pre-rinse option




- 1 Stop sample flow.
- 2 Slightly squeeze the exhausted cation exchanger bottle [E] before removing.  
⇒ *Thus no water will spill out of the flow cell when loosening the bottle.*
- 3 Unscrew and carefully remove the exhausted cation exchanger bottle [E].
- 4 Fill high purity water into the new cation exchanger bottle [C], until the water level in the bottle reaches the beginning of the thread.
- 5 Carefully, without spilling water, push the cation exchanger bottle over the inlet filter holder [D] into the bottle holder [B].
- 6 Screw the cation exchanger bottle into the bottle holder.  
**⚠** *Do not tighten the bottle too firmly, this could damage the gasket.*

- 7 Navigate to menu <Maintenance>, <Change of Resin>, press [Enter] and set it to <Yes>.
- 8 Open and adjust the sample flow.
- 9 Pre-rinse the new cation exchanger resin until the display shows stable measuring values.

**with pre-rinse  
option**

Step 1 to 3 same procedure as in “**without pre-rinse option**”:




- 4 Unscrew and carefully remove the pre-rinsed cation exchanger bottle [D] from the pre-rinse holder [C].
- 5 Carefully, without spilling water, push the cation exchanger bottle [D] over the inlet filter holder [E] into the bottle holder [B].
- 6 Screw the cation exchanger bottle into the bottle holder.  
**⚠ Do not tighten the bottle too firmly, this could damage the gasket.**
- 7 Install a new bottle with fresh, unused resin into the pre-rinse bottle holder [C].  
⇒ *The new c.ation exchanger resin will be pre-rinsed and ready for use if the next exchange is necessary.*



### Operation time 1 liter Swan resin

This graphic shows the average exhaust time (flow 6 l/h) and must be verified by the user.




Cation Conductivity.

Operational Days for 1 l of Cation Exchange Resin with an Exchange Capacity of 1.8 eq/l.

Flow Rate 6 l/h Alkalization with Ammonia. (Safety Margin of 15% Subtracted).


## 6.5. Changing the inlet filter

The inlet filter of the cation exchanger prevents the resin from entering the flow cell. It is located in the inlet filter holder [B].



- 1 Stop sample flow.
- 2 Slightly squeeze the cation exchanger bottle [E] before removing.  
⇒ *Thus no water will spill out of the flow cell when loosening the bottle.*
- 3 Unscrew and carefully remove the cation exchanger bottle.
- 4 For better access to the allen screws [C] unscrew and remove the filter holder [B] from the bottle holder [A].
- 5 Loosen the 4 allen screws with a 1.5 mm allen key.
- 6 Carefully remove the inlet filter [D] with a screw driver no.0 from the inlet filter holder.
- 7 Insert a new inlet filter.
- 8 Tighten the 4 allen screws slightly.
- 9 Screw the cation exchanger bottle into the bottle holder.  
⚠ *Do not tighten the bottle too firmly, this could damage the gasket.*

## 6.6. Tube Connections



- |   |  |
|---|--|
| <b>A</b> Pre-rinse inlet                  | <b>D</b> Deaeration tube Cation exchanger bottle |
| <b>B</b> Per-rinse outlet                 | <b>E</b> Tube fittings                           |
| <b>C</b> Deaeration tube pre-rinse bottle | <b>F</b> Sample collector                        |


## 6.7. Replace the Deaeration Tubes

Depending on your application, it might be necessary to change the deaeration tube, e.g. when contaminated with iron.

**Note:** There are two different tubes:


- ◆ The deaeration tube [F] of the cation exchanger bottle has an inner diameter of 1 mm.
- ◆ The deaeration tube [E] of the pre-rinse bottle, has an inner diameter of 2 mm.

- Preparation**
- 1 Close the main tap to stop the sample flow.
  - 2 Remove cation exchanger bottle from the bottle holder [H].



- |  |  |
|--|--|
| <b>A</b> Flow cell                               | <b>G</b> Tube fitting                          |
| <b>B</b> Flowmeter                               | <b>H</b> Bottle holder cation exchanger bottle |
| <b>C</b> Pre-rinse inlet                         | <b>I</b> Panel                                 |
| <b>D</b> Sample collector                        | <b>J</b> Bottle holder pre-rinse bottle        |
| <b>E</b> Deaeration tube pre-rinse bottle        | <b>K</b> Flow regulating valve                 |
| <b>F</b> Deaeration tube cation exchanger bottle |  |

### 6.7.1 Exchange deaeration tube of cation exchanger bottle

- 1 Remove the inlet tube [C] to the pre-rinsed cation exchanger bottle from the flowmeter [B].
- 2 Remove the flowmeter [B] from the flow cell [A].
- 3 Remove the sample collector [D] from the panel [I].
- 4 Unscrew and remove the tube fittings of the deaeration tubes [E] and [F] from the sample connector.
- 5 Unscrew and remove the bottle holder [H] from the flow cell [A].
- 6 Unscrew and remove the tube fitting [G] from the bottle holder [H].
- 7 Replace the 1 mm deaeration tube [F].
- 8 Screw the tube fitting into the bottle holder and tighten it.
- 9 Screw the bottle holder to the flow cell.
- 10 Screw the cation exchanger bottle into the bottle holder.  
 *Do not tighten the bottle too firmly, this could damage the gasket.*
- 11 Before installing the sample collector [D] and the flowmeter [B] replace the deaeration tube [E], see following chapter.

### 6.7.2 Exchange deaeration tube of pre-rinse bottle

- 1 Unscrew and remove the flow regulating valve [K], with a 14 mm open-end wrench from the flow cell.
- 2 Unscrew and remove the tube fitting from the bottle holder [J].
- 3 Replace the 2 mm deaeration tube [E].
- 4 Screw the flow regulating valve into the flow cell and tighten it well.

#### Assemble

- 1 Screw the sample connector onto the panel.
- 2 Screw the flow meter [B] onto the flow cell [A].
- 3 Connect the inlet tube [C] to the pre-rinsed cation exchanger bottle with the elbow union of the flowmeter [B].

## **6.8. Longer Stop of Operation**

- 1** Stop sample flow.
- 2** Slightly squeeze the ion exchanger bottle.  
⇒ *Thus no water will spill out of the flow cell when loosening the bottle.*
- 3** Unscrew and carefully remove the ion exchanger bottle with the exhausted resin.
- 4** Close the ion exchanger bottle with the screw cover and store it in a frost-protected room.
- 5** Screw an empty bottle into the bottle holder.
- 6** Shut off power of the instrument.

## 7. Troubleshooting

This chapter provides some hints to make troubleshooting easier. For any detailed information how to handle/clean parts please see chapter [Maintenance](#), p. 37.

For any detailed information how to program the instrument please see chapter [Program List and Explanations](#), p. 58.

If you need help please contact your local distributor. Note serial number of instrument and all diagnostic values before.

### Conditions for pH calculation

- ♦ only 1 alkalization agent (acid-base pair) in the sample (no mixture)
- ♦ the contamination is mostly NaCl
- ♦ phosphate concentration is < 0.5 ppm
- ♦ if pH value is < 8, the concentration of contaminat must be small compared to the concentration of the alkalization agent
- ♦ pH value is > 7.5, and < 11.5

Problem	Possible Reason
Cond. value <0.055 $\mu\text{S}/\text{cm}$	♦ Air bubble at sensor tip or sensor in air.
High cation cond. after start-up	♦ Cation exchanger resin not rinsed. Use Swan cation exchanger resin.
No pH/alkalization agent value available in display, relay, signal output	<ul style="list-style-type: none"> <li>♦ Switch on calculations in Installation, Sensor, Miscellaneous, Calculations.</li> <li>♦ Afterwards program screen 1 and 2 in Operation, Display, Screen 1, Screen 2.</li> </ul>



## 7.1. Error List

### Error

Non-fatal Error. Indicates an alarm if a programmed value is exceeded.

Such Errors are marked **E0xx** (bold and black).


### Fatal Error (blinking symbol)

Control of dosing devices is interrupted.

The indicated measured values are possibly incorrect.

Fatal Errors are divided in the following two categories:


- ◆ Errors which disappear if correct measuring conditions are recovered (i.e. Sample Flow low).  
Such Errors are marked **E0xx** (bold and orange)
- ◆ Errors which indicate a hardware failure of the instrument.  
Such Errors are marked **E0xx** (bold and red)




### Error or fatal Error

Error not yet acknowledged.

Check **Pending Errors 1.1.5** and take corrective action.



Navigate to menu <Messages>/<Pending Errors>.



Press [ENTER] to acknowledge the Pending Errors.

⇒ *The Error is reset and saved in the Message List.*



<b>Error</b>	<b>Description</b>	<b>Corrective action</b>
<b>E001</b>	Cond. 1 Alarm high	<ul style="list-style-type: none"> <li>– check process</li> <li>– check programmed value, see <a href="#">5.3.1.1, p. 69</a></li> </ul>
<b>E002</b>	Cond. 1 Alarm low	<ul style="list-style-type: none"> <li>– check process</li> <li>– check programmed value, see <a href="#">5.3.1.1, p. 69</a></li> </ul>
<b>E003</b>	Cond. 2 Alarm high	<ul style="list-style-type: none"> <li>– check process</li> <li>– check programmed value, see <a href="#">5.3.1.1.2.1, p. 69</a></li> </ul>
<b>E004</b>	Cond. 2 Alarm low	<ul style="list-style-type: none"> <li>– check process</li> <li>– check programmed value, see <a href="#">5.3.1.1.2.25, p. 69</a></li> </ul>
<b>E007</b>	Temp. 1 high	<ul style="list-style-type: none"> <li>– check process</li> <li>– check programmed value, see <a href="#">5.3.1.1.4, p. 70</a></li> </ul>
<b>E008</b>	Temp. 1 low	<ul style="list-style-type: none"> <li>– check process</li> <li>– check programmed value, see <a href="#">5.3.1.1.4, p. 70</a></li> </ul>
<b>E009</b>	Sample Flow high	<ul style="list-style-type: none"> <li>– check sample inlet pressure</li> <li>– check programmed value, see <a href="#">5.3.1.3.2, p. 71</a></li> </ul>
<b>E010</b>	Sample Flow low	<ul style="list-style-type: none"> <li>– check sample inlet pressure</li> <li>– Check flow regulating valve</li> <li>– check programmed value, see <a href="#">5.3.1.3.35, p. 71</a></li> </ul>
<b>E011</b>	Temp. 1 shorted	<ul style="list-style-type: none"> <li>– Check wiring of temperature sensor</li> <li>– Check temperature sensor</li> </ul>
<b>E012</b>	Temp. 1 disconnected	<ul style="list-style-type: none"> <li>– Check wiring of temperature sensor</li> <li>– Check temperature sensor</li> </ul>
<b>E013</b>	Case Temp. high	<ul style="list-style-type: none"> <li>– check case/environment temperature</li> <li>– check programmed value, see <a href="#">5.3.1.4.1, p. 71</a></li> </ul>
<b>E014</b>	Case Temp. low	<ul style="list-style-type: none"> <li>– check case/environment temperature</li> <li>– check programmed value, see <a href="#">5.3.1.4.2, p. 72</a></li> </ul>



<b>Error</b>	<b>Description</b>	<b>Corrective action</b>
<b>E015</b>	pH Calculation undef.	– Calculated pH value < 7.5 or > 11.5
<b>E017</b>	Control time-out	– Check control device or programming in Installation, Relay contact, Relay 1/2 <a href="#">5.3.2 and 5.3.3, p. 72</a>
<b>E019</b>	Temp. 2 shortened	– check wiring of temperature sensor – check temp. sensor
<b>E020</b>	Temp. 2 disconnected	– check wiring of temperature sensor – check temp. sensor
<b>E024</b>	Input active	– See If Fault Yes is programmed in Menu see <a href="#">5.3.4, p. 75</a>
<b>E026</b>	IC LM75	– call service
<b>E028</b>	Signal output open	– check wiring on signal outputs 1 and 2
<b>E030</b>	EEProm Frontend	– call service
<b>E031</b>	Cal. Recout	– call service
<b>E032</b>	Wrong Frontend	– call service
<b>E033</b>	pH Alarm high	– check process – check programmed value, see <a href="#">5.3.1.1.4.1, p. 70</a>
<b>E034</b>	pH Alarm low	– check process – check programmed value, see <a href="#">5.3.1.1.4.25, p. 70</a>
<b>E035</b>	Alkali Alarm high	– check process – check programmed value, see <a href="#">5.3.1.1.5, p. 70</a>
<b>E036</b>	Alkali Alarm low	– check process – check programmed value, see <a href="#">5.3.1.1.5, p. 70</a>
<b>E037</b>	Temp. 2 Alarm high	– check process – check programmed value, see <a href="#">5.3.1.2.2.1, p. 71</a>

<b>Error</b>	<b>Description</b>	<b>Corrective action</b>
<b>E038</b>	Temp. 2 Alarm low	– check process – check programmed value, see <a href="#">5.3.1.2.2.25, p. 71</a>
<b>E049</b>	Power-on	– none, normal status
<b>E050</b>	Power-down	– none, normal status
<b>E067</b>	Resin depleted	– Exchange the cation exchanger bottle, see <a href="#">Changing the Cation Exchanger, p. 39</a>



## 7.2. Replacing Fuses



### WARNING

#### External Voltage.


External supplied devices connected to relay 1 or 2 or to the alarm relay can cause electrical shocks

- ♦ Make sure that the devices connected to the following contacts are disconnected from the power before resuming installation.
  - relay 1
  - relay 2
  - alarm relay

When a fuse has blown, find out the cause and fix it before replace it with a new one.

Use tweezers or needle-nosed pliers to remove the defective fuse.

Use original fuses provided by SWAN only.



- A** AC variant: 1.6 AT/250V Instrument power supply  
DC variant: 3.15 AT/250 V Instrument power supply
- B** 1.0 AT/250V Relay 1
- C** 1.0 AT/250V Relay 2
- D** 1.0 AT/250V Alarm relay
- E** 1.0 AF/125V Signal output 2
- F** 1.0 AF/125V Signal output 1
- G** 1.0 AF/125V Signal output 3

## 8. Program Overview

For explanations about each parameter of the menus see [Program List and Explanations, p. 58](#)

- ♦ Menu 1 **Messages** informs about pending errors and maintenance tasks and shows the error history. Password protection possible. No settings can be modified.
- ♦ Menu 2 **Diagnostics** is always accessible for everybody. No password protection. No settings can be modified.
- ♦ Menu 3 **Maintenance** is for service: Calibration, simulation of outputs and set time/date. Please protect with password.
- ♦ Menu 4 **Operation** is for the user, allowing to set limits, alarm values, etc. The presetting is done in the menu Installation (only for the System engineer). Please protect with password.
- ♦ Menu 5 **Installation**: Defining assignment of all inputs and outputs, measuring parameters, interface, passwords, etc. Menu for the system engineer. Password strongly recommended.

### 8.1. Messages (Main Menu 1)

<b>Pending Errors</b> 1.1*	<i>Pending Errors</i>	1.1.5*	* Menu numbers
<b>Maintenance List</b> 1.2*	<i>Maintenance List</i>	1.2.5*	
<b>Message List</b> 1.3*	<i>Number</i> <i>Date, Time</i>	1.3.1*	

## 8.2. Diagnostics (Main Menu 2)

<b>Identification</b> 2.1*	<b>Designation</b> AMI DeltaconP <b>Version</b> V6.21-04/18 <b>Factory Test</b> 2.1.4* <i>Instrument</i> 2.1.4.1* <i>Motherboard</i> <i>Front End</i> <b>Operating Time</b> 2.1.5* <i>Years / Days / Hours / Minutes / Seconds</i> 2.1.5.1*	* Menu numbers
<b>Sensors</b> 2.2*	<b>Conductivity</b> 2.2.1* <i>Sensor 1</i> <i>Current value</i> 2.2.1.1.1* <i>Raw value</i> <i>Cell constant</i> <i>Sensor 2</i> <i>Current value</i> 2.2.1.1.2* <i>Raw value</i> <i>Cell constant</i> <b>Miscellaneous</b> 2.2.2* <i>Case Temp.</i> 2.2.2.1*	
<b>Sample</b> 2.3*	<i>Sample ID</i> 2.3.1* <i>Sample Flow</i> <i>Sample Flow</i> 2.3.2.1* <i>Raw value</i> <i>Sample Temp.</i> <i>Temp.1</i> 2.3.3.1* 2.3.3* <i>(Pt1000)</i> <i>Temp.2</i> <i>(Pt1000)</i>	
<b>I/O State</b> 2.4*	<i>Alarm Relay</i> 2.4.1* <i>Relay 1/2</i> 2.4.2* <i>Input</i> <i>Signal Output 1/2</i>	
<b>Interface</b> 2.5*	<i>Protocol</i> 2.5.1* <i>Baud rate</i>	(only with RS485 interface)

### 8.3. Maintenance (Main Menu 3)

<b>Simulation</b>	<i>Alarm Relay</i>	3.1.1*	*Menu numbers
3.1*	<i>Relay 1</i>	3.1.2*	
	<i>Relay 2</i>	3.1.3*	
	<i>Signal Output 1</i>	3.1.4*	
	<i>Signal Output 2</i>	3.1.5*	
<b>Set Time</b>	<i>(Date), (Time)</i>		
3.2*			
<b>Change of Resin</b>	<i>(Only if &lt;Monitoring of Resin&gt; is set to &lt;Yes&gt;)</i>		
3.3*			

### 8.4. Operation (Main Menu 4)

<b>Sensors</b>	<i>Filter Time Const.</i>	4.1.1*		
4.10*	<i>Hold after Cal</i>	4.1.2*		
<b>Relay Contacts</b>	<b>Alarm Relay</b>	<b>Cond. 1 (sc)</b>	<i>Alarm High</i>	4.2.1.1.1*
4.2*	4.2.1*	4.2.1.1*	<i>Alarm Low</i>	4.2.1.1.25*
			<i>Hysteresis</i>	4.2.1.1.35*
			<i>Delay</i>	4.2.1.1.45*
		<b>Cond. 2 (cc)</b>	<i>Alarm High</i>	4.2.1.2.1*
		4.2.1.2*	<i>Alarm Low</i>	4.2.1.2.25*
			<i>Hysteresis</i>	4.2.1.2.35*
			<i>Delay</i>	4.2.1.2.45*
	<b>Relay 1/2</b>	<i>Parameter</i>		
	4.2.2*/4.2.3*	<i>Setpoint</i>	4.2.x.200*	
		<i>Hysteresis</i>	4.2.x.300*	
		<i>Delay</i>	4.2.x.40*	
	<b>Input</b>	<i>Active</i>	4.2.4.1*	
	4.2.4*	<i>Signal Outputs</i>	4.2.4.2*	
		<i>Output / Control</i>	4.2.4.3*	
		<i>Fault</i>	4.2.4.4*	
		<i>Delay</i>	4.2.4.5*	
<b>Logger</b>	<i>Log Interval</i>	4.3.1*		
4.3*	<i>Clear Logger</i>	4.3.2*		

<b>Display</b> 4.4*	<b>Screen 1</b> 4.4.1*	Row 1	4.4.1.1*	* Menu numbers
		Row 2	4.4.1.2*	
		Row 3	4.4.1.3*	
	<b>Screen 2</b> 4.4.2*	Row 1	4.4.2.1*	
		Row 2	4.4.2.2*	
		Row 3	4.4.2.3*	

## 8.5. Installation (Main Menu 5)

<b>Sensors</b> 5.1*	<b>Miscellaneous</b> 5.1.1*	<i>Calculations</i>	5.1.1.1*		
		<i>Maes. unit</i>	5.1.1.2*		
		<i>Monitoring of resin</i>	5.1.1.3*		
		<i>Resin Capacity</i>	5.1.1.4*		
		<i>Volume of resin</i>	5.1.1.5*		
	<b>Sensor parameters</b> 5.1.2*	<b>Sensor 1</b> 5.1.2.1*	Cell Constant		5.1.2.1.1*
			Temp. Corr.		5.1.2.1.2*
			Cable length		5.1.2.1.3*
			<b>Temp. comp.</b>		Comp.
			5.1.2.1.5*		5.1.2.1.5.1*
		<b>Sensor 2</b> 5.1.2.2*	Cell Constant		5.1.2.2.1*
			Temp. Corr.		5.1.2.2.2*
			Cable length		5.1.2.2.3*
<b>Temp. comp.</b>				Comp.	
5.1.2.2.5*				5.1.2.2.5.1*	
<b>Flow</b> 5.1.3*	<b>Sensor</b>		5.1.3.1*		
<b>Signal Outputs</b> 5.2*	<b>Signal Output 1/2</b> 5.2.1/5.2.2*	<i>Parameter</i>	5.2.1.1/5.2.2.1*		
		<i>Current Loop</i>	5.2.1.2/5.2.2.2*		
		<i>Function</i>	5.2.1.3/5.2.2.3*		
		<b>Scaling</b>	<i>Range Low</i>	5.2.x.40.10/11*	
	5.2.x.40	<i>Range High</i>	5.2.x.40.20/21*		
<b>Relay Contacts</b> 5.3*	<b>Alarm Relay</b> 5.3.1*	<b>Conductivity</b>	<b>Cond. 1 (sc)</b>	<i>Alarm High</i>	
		5.3.1.1*	5.3.1.1.1*	<i>Alarm Low</i>	
				<i>Hysteresis *</i>	
				<i>Delay</i>	



			<b>Cond. 2 (cc)</b>	<i>Alarm High</i>
			5.3.1.1.2*	<i>Alarm Low</i>
				<i>Hysteresis *</i>
				<i>Delay</i>
		<b>Sample Temp.</b>	<b>Temp. 1</b>	<i>Alarm High</i>
		5.3.1.2*	5.3.1.2.1*	<i>Alarm Low</i>
			<b>Temp. 2</b>	<i>Alarm High</i>
			5.3.1.2.2*	<i>Alarm Low</i>
		<b>Sample Flow</b>	<i>Flow Alarm</i>	5.3.1.3.1*
		5.3.1.3*	<i>Alarm High</i>	5.3.1.3.2
			<i>Alarm Low</i>	5.3.1.3.35
		<b>Case Temp.</b>	<i>Alarm High</i>	5.3.1.4.1*
		5.3.1.4*	<i>Alarm low</i>	5.3.1.4.2*
		<i>Function</i>	5.3.2.1/ 5.3.3.1*	
		<i>Parameter</i>	5.3.2.20/ 5.3.3.20*	
		<i>Setpoint</i>	5.3.2.300 / 5.3.3.301*	
		<i>Hysteresis</i>	5.3.2.400/ 5.3.3.401*	
		<i>Delay</i>	5.3.2.50/ 5.3.3.50*	
		<i>Active</i>	5.3.4.1*	
		<i>Signal Outputs</i>	5.3.4.2*	
		<i>Output/Control</i>	5.3.4.3*	
		<i>Fault</i>	5.3.4.4*	
		<i>Delay</i>	5.3.4.5*	
	<b>Relay 1/2</b>			
	5.3.2/5.3.3*			
	<b>Input</b>			
	5.3.4*			
<b>Miscellaneous</b>	<i>Language</i>	5.4.1*		
5.4*	<i>Set defaults</i>	5.4.2*		
	<i>Load Firmware</i>	5.4.3*		
	<b>Password</b>	<i>Messages</i>	5.4.4.1*	
	5.4.4*	<i>Maintenance</i>	5.4.4.2*	
		<i>Operation</i>	5.4.4.3*	
		<i>Installation</i>	5.4.4.4*	
	<i>Sample ID</i>	5.4.5*		
	<i>Line break detection</i>	5.4.6*		
<b>Interface</b>	<i>Protocol</i>	5.5.1*		(only with RS485 interface)
5.5*	<i>Device Address</i>	5.5.21*		
	<i>Baud Rate</i>	5.5.31*		
	<i>Parity</i>	5.5.41*		

\* Menu numbers

## 9. Program List and Explanations

### 1 Messages

#### 1.1 Pending Errors

- 1.1.5 Provides the list of active errors with their status (active, acknowledged). If an active error is acknowledged, the alarm relay is active again. Cleared errors are moved to the Message list.

#### 1.2 Maintenance List

- 1.2.5 Provides the list of necessary maintenance. Cleared maintenance messages are moved to the Message list.

#### 1.3 Message List

- 1.3.1 Shows the error history: Error code, date / time of issue and status (active, acknowledged, cleared). 65 errors are memorized. Then the oldest error is cleared to save the newest error (circular buffer).

### 2 Diagnostics

In diagnostics mode, the values can only be viewed, not modified.

#### 2.1 Identification

**Desig.:** Designation of the instrument.

**Version:** Firmware of instrument (e.g. V6.21-04/18).

- 2.1.4 **Factory Test:** Test date of the Instrument, Motherboard and Frontend.
- 2.1.5 **Operating Time:** Years / Days / Hours / Minutes / Seconds

#### 2.2 Sensors

##### 2.2.1 Conductivity:

- 2.2.1.1 **Sensor 1:** Shows the  
*Current value* in  $\mu\text{S}$   
*Raw value* in  $\mu\text{S}$   
Cell Constant
- 2.2.1.2 **Sensor 2:** Shows the  
*Current value* in  $\mu\text{S}$   
*Raw value* in  $\mu\text{S}$   
Cell Constant

**2.2.2 Miscellaneous:**

2.2.2.1 *Case Temp*: Shows the current temperature in [°C] inside the transmitter.

**2.3 Sample**

2.3.1 *Sample ID*: Shows the identification assigned to a sample. This identification is defined by the user to identify the location of the sample.

**2.3.2 Sample Flow**: Shows the current sample flow in l/h and the Raw Value in Hz.

The Sample flow must be above 5 l/h.

**2.3.3 Sample Temp**:

2.3.3.1 *Temp 1*: Shows the current sample temperature at sensor 1 in °C.  
*(Pt 1000)*: Shows the current temperature at sensor 1 in Ohm.  
*Temp 2*: Shows the current temperature at sensor 2 in °C.  
*(Pt 1000)*: Shows the current temperature at sensor 2 in Ohm.

**2.4 I/O State**

Shows current status of all in- and outputs.

2.4.1/2.4.2

<i>Alarm relay</i> :	Active or inactive.
<i>Relay 1/2</i> :	Active or inactive.
<i>Input</i> :	Open or closed.
<i>Signal output 1/2</i> :	Actual current in mA
<i>Signal output 3</i> :	Actual current in mA (if option is installed)

**2.5 Interface**

Only available if optional interface is installed.  
Review programmed communication settings.

**3 Maintenance**

**3.1 Simulation**

To simulate a value or a relay state, select the

- ♦ alarm relay
- ♦ relay 1/2
- ♦ signal output 1/2

with the [▲] or [▼] key.

Press the <Enter> key.

Change the value or state of the selected item with the [▲] or [▼] key.

Press the <Enter> key.



⇒ *The value is simulated by the relay/signal output.*

<i>Alarm relay:</i>	Active or inactive
<i>Relay 1/2:</i>	Active or inactive
<i>Signal output 1/2:</i>	Actual current in mA
<i>Signal output 3:</i>	Actual current in mA (if option is installed)

At the absence of any key activities, the instrument will switch back to normal mode after 20 min. If you quit the menu, all simulated values will be reset.

## 3.2 Set Time

Adjust date and time.

## 3.3 Change of Resin

If <Monitoring of Resin> in menu <Installation>/<Miscellaneous> is set to <Yes>, the parameter <Change of Resin> has to be set to <Yes> after each time the cation exchanger bottle has been replaced.

# 4 Operation

## 4.1 Sensors

- 4.1.1 *Filter Time Constant:* Used to damp noisy signals. The higher the filter time constant, the slower the system reacts to changes of the measured value.  
Range: 5–300 Sec
- 4.1.2 *Hold after Cal.:* Delay permitting the instrument to stabilize again after calibration. During calibration plus hold-time, the signal outputs are frozen (held on last valid value), alarm values, limits are not active.  
Range: 0–6'000 Sec

## 4.2 Relay Contacts

See [Relay Contacts](#), p. 25

### 4.3 Logger

The instrument is equipped with an internal logger. The logger data can be copied to a PC with an USB stick if option USB interface is installed.

The logger can save approx. 1500 data records. Records consist of: Date, time, alarms, measured value, measured value uncompensated, temperature, flow.

Range: 1 Second to 1 hour

- 4.3.1 *Log Interval:* Select a convenient log interval. Consult the table below to estimate the max logging time. When the logging buffer is full, the oldest data record is erased to make room for the newest one (circular buffer).

Interval	1 s	5 s	1 min	5 min	10 min	30 min	1 h
Time	25 min	2 h	25 h	5 d	10 d	31 d	62 d

- 4.3.2 *Clear Logger:* If confirmed with **yes**, the complete logger data is deleted. A new data series is started.
- 4.3.3 *Eject USB Stick:* With this function all logger data are copied to the USB stick before the USB stick is deactivated. Only visible if the optional USB interface is installed.

### 4.4 Display

Process values are displayed on two screens. Toggle screens with the [▲] key. Each screen displays max. 3 process values.

- 4.4.1 Screen 1
- 4.4.1.1 Row 1
- 4.4.1.2 Row 2
- 4.4.1.3 Row 3

Possible settings for all rows are:

- ◆ None
- ◆ Cond 1 (sc)
- ◆ Cond 2 (cc)
- ◆ Difference
- ◆ pH (if <Calculations> = yes)
- ◆ Ammonia (depends on the settings in <Sensor parameters>/<Temp. comp.>)

- 4.4.2 Screen 2  
 Same as screen 1.

## 5 Installation

### 5.1 Sensors

#### 5.1.1 Miscellaneous:

- 5.1.1.1 *Calculations:* Select "yes" if pH and ammonia concentrations should be calculated. pH and ammonia are now available on screen 1 or 2, on the signal outputs and as alarm or limit values.
- 5.1.1.2 *Meas. unit:* Choose the measuring unit as  $\mu\text{S}/\text{cm}$  or  $\mu\text{S}/\text{m}$
- 5.1.1.3 *Monitoring of resin:* Select "yes" if consumption of cation resin should be calculated and displayed. Replacement of exhausted resin must now be confirmed in "Maintenance".
- 5.1.1.4 *Resin Capacity:* Enter the resin capacity.  
Range: 0.5–4.0 eq/l
- 5.1.1.5 *Volume of resin:* Enter the volume of the resin bottle.  
Range: 0.5–30.0 l

#### 5.1.2 Sensor parameters:

##### 5.1.2.1 Sensor 1

- 5.1.2.1.1 *Cell Constant:* Enter the cell constant printed on the sensor label.  
Range:  $0.0300\text{ cm}^{-1}$  to  $0.0600\text{ cm}^{-1}$
- 5.1.2.1.2 *Temp. Corr:* Enter the temperature correction printed on the sensor label.  
Range:  $-1\text{ }^{\circ}\text{C}$  to  $1\text{ }^{\circ}\text{C}$
- 5.1.2.1.3 *Cable length:* Enter the cable length. Set the cable length to 0.0 m if the sensors are installed in the flow cell on the AMI monitor.  
Range: 0.0 m to 30.0 m

##### 5.1.2.1.5 Temp. comp:

- 5.1.2.1.5.1 *Comp.:* Available compensation models:
- ◆ Strong acids (Never select strong acids for sensor 1!)
  - ◆ Strong bases
  - ◆ Ammonia
  - ◆ Morpholine
  - ◆ Ethanolamines
  - ◆ Neutral salts
  - ◆ High purity water
  - ◆ Coefficient
  - ◆ none

**5.1.2.2 Sensor 2**

5.1.2.2.1 *Cell Constant*: Enter the cell constant printed on the sensor label.

Range: 0.0300 cm<sup>-1</sup> to 0.0600 cm<sup>-1</sup>

5.1.2.2.2 *Temp. Corr.*: Enter the temperature correction printed on the sensor label.

Range: -1 °C to 1 °C

5.1.2.2.3 *Cable length*: Enter the cable length. Set the cable length to 0.0 m if the sensors are installed in the flow cell on the AMI monitor.

Range: 0.0 m to 30.0 m

**5.1.2.2.5 Temp. comp:**

5.1.2.2.5.1 *Comp.*: Available compensation models:

- ◆ Strong acids

**5.1.3 Flow**

5.1.3.1 *Sensor*: Choose between <Yes> or <No>. <Yes> is set by default. If Sensor is set to <No>, the flow monitoring is deactivated and the signal <Sample flow> on the Signal Outputs and Relay 1 and 2 is not available.

## 5.2 Signal Outputs

*Note: The navigation in the menu <Signal Output 1> and <Signal Output 2> is equal. For reason of simplicity only the menu numbers of Signal Output 1 are used in the following.*

**5.2.1 Signal Output 1:** Assign process value, the current loop range and a function to each signal output.

5.2.1.1 *Parameter*: Assign one of the process values to the signal output.

Available values:

- ◆ Cond 1 (cc)
- ◆ Cond 2 (sc)
- ◆ Temp. 1
- ◆ Temp. 2
- ◆ Difference
- ◆ Sample flow
- ◆ pH
- ◆ Ammonia

5.2.1.2 *Current Loop*: Select the current range of the signal output. Make sure the connected device works with the same current range. Available ranges: 0–20 mA or 4–20 mA





**Parameter Cond. 1(sc):**

5.2.1.40.10 Range low: 0.000 –3000  $\mu$ S

5.2.1.40.20 Range high: 0.000 –3000  $\mu$ S

**Parameter Cond. 2(cc):**

5.2.1.40.11 Range low: 0.000–3000  $\mu$ S

5.2.1.40.21 Range high: 0.000 –3000  $\mu$ S

**Parameter Temp. 1**

5.2.1.40.13 Range low: -25 to +270 °C

5.2.1.40.23 Range high: -25 to +270 °C

**Parameter Temp. 2**

5.2.1.40.14 Range low: -25 to +270 °C

5.2.1.40.24 Range high: -25 to +270 °C

**Parameter Difference**

5.2.1.40.16 Range low: 0.000 –3000  $\mu$ S

5.2.1.40.26 Range high: 0.000 –3000  $\mu$ S

**Parameter Sample flow**

5.2.1.40.17 Range low: 0.0 –20 l/h

5.2.1.40.27 Range high: 0.0 –20 l/h

**Parameter pH**

5.2.1.40.18 Range low: 0.00 –14 pH

5.2.1.40.28 Range high: 0.00 –14 pH

**Parameter Ammonia**

5.2.1.40.19 Range low: 0.00 –500 ppm

5.2.1.40.29 Range high: 00.0 –500 ppm


**As control output**

Signal outputs can be used for driving control units. We distinguish different kinds of controls:

- ◆ *P-controller*: The controller action is proportional to the deviation from the setpoint. The controller is characterized by the P-Band. In the steady-state, the setpoint will never be reached. The deviation is called steady-state error. Parameters: setpoint, P-Band
- ◆ *PI-controller*: The combination of a P-controller with an I-controller will minimize the steady-state error. If the reset time is set to zero, the I-controller is switched off. Parameters: setpoint, P-Band, reset time.
- ◆ *PD-controller*: The combination of a P-controller with a D-controller will minimize the response time to a fast change of the process value. If the derivative time is set to zero, the D-controller is switched off. Parameters: setpoint, P-Band, derivative time.
- ◆ *PID-controller*: The combination of a P-, an I- and a D-controller allows a proper control of the process. Parameters: setpoint, P-Band, reset time, derivative time.

Ziegler-Nichols method for the optimization of a PID controller:

**Parameters:** Setpoint, P-Band, Reset time, Derivative time



- A** Response to maximum control output     $X_p = 1.2/a$   
**B** Tangent on the inflection point         $T_n = 2L$   
**X** Time     $T_v = L/2$

The point of intersection of the tangent with the respective axis will result in the parameters a and L.

Consult the manual of the control unit for connecting and programming details. Choose control upwards or downwards.

### **Control upwards or downwards**

*Setpoint:* User-defined process value for the selected parameter.

*P-Band:* Range below (upwards control) or above (downwards control) the set-point, within the dosing intensity is reduced from 100% to 0% to reach the setpoint without overshooting.

- 5.2.1.43 Control Parameters:** if Parameters = Cond. 1(sc)
  - 5.2.1.43.10 Setpoint  
Range: 0.000 – 3000  $\mu$ S
  - 5.2.1.43.20 P-Band:  
Range: 0.000 – 3000  $\mu$ S
  
- 5.2.1.43 Control Parameters:** if Parameters = Cond. 2(cc)
  - 5.2.1.43.11 Setpoint  
Range: 0.000 – 3000  $\mu$ S
  - 5.2.1.43.21 P-Band:  
Range: 0.000 – 3000  $\mu$ S
  
- 5.2.1.43 Control Parameters:** if Parameters = Temp. 1
  - 5.2.1.43.13 Setpoint  
Range: -25 to +270 °C
  - 5.2.1.43.23 P-Band:  
Range: -25 to +270 °C
  
- 5.2.1.43 Control Parameters:** if Parameters = Temp. 2
  - 5.2.1.43.14 Setpoint  
Range: -25 to +270 °C
  - 5.2.1.43.24 P-Band:  
Range: -25 to +270 °C
  
- 5.2.1.43 Control Parameters:** if Parameters = Difference
  - 5.2.1.43.16 Setpoint  
Range: 0.000 – 3000  $\mu$ S
  - 5.2.1.43.26 P-Band:  
Range: 0.000 – 3000  $\mu$ S
  
- 5.2.1.43 Control Parameters:** if Parameters = Sample flow
  - 5.2.1.43.17 Setpoint  
Range: 0.0 – 20 l/h
  - 5.2.1.43.27 P-Band:  
Range: 0.0 – 20 l/h



- 5.2.1.43 Control Parameters:** if Parameters = pH
- 5.2.1.43.18 Setpoint  
Range: 0.00 – 14 pH
- 5.2.1.43.28 P-Band:  
Range: 0.00 – 14 pH
- 5.2.1.43 Control Parameters:** if Parameters = Ammonia
- 5.2.1.43.19 Setpoint  
Range: 0.00 – 500 ppm
- 5.2.1.43.29 P-Band:  
Range: 0.00 – 500 ppm
- 5.2.1.43.3 *Reset time:* The reset time is the time till the step response of a single I-controller will reach the same value as it will be suddenly reached by a P-controller.  
Range: 0–9'000 sec
- 5.2.1.43.4 *Derivative time:* The derivative time is the time till the ramp response of a single P-controller will reach the same value as it will be suddenly reached by a D-controller.  
Range: 0–9'000 sec
- 5.2.1.43.5 *Control timeout:* If a controller action (dosing intensity) is constantly over 90% during a defined period of time and the process value does not come closer to the setpoint, the dosing process will be stopped for safety reasons.  
Range: 0–720 min

## 5.3 Relay Contacts

- 5.3.1 Alarm Relay:** The alarm relay is used as cumulative error indicator. Under normal operating conditions the contact is active.
- The contact is inactive at:
- ◆ Power loss
  - ◆ Detection of system faults like defective sensors or electronic parts
  - ◆ High case temperature
  - ◆ Process values out of programmed ranges.

Program alarm levels, hysteresis values and delay times for the following parameters:

- ◆ Cond.1 (sc)
- ◆ Cond.2 (cc)
- ◆ pH
- ◆ Ammonia
- ◆ Sample Temp. 1
- ◆ Sample Temp. 2
- ◆ Sample Flow
- ◆ Case Temperature low

**5.3.1.1 Conductivity**

**5.3.1.1.1 Cond. 1 (sc)**

5.3.1.1.1.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E001, is displayed in the message list.

Range: 0.000 –3000  $\mu$ S

5.3.1.1.1.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay is activated and E002 is displayed in the message list.

Range: 0.000 –3000  $\mu$ S

5.3.1.1.1.35 *Hysteresis:* Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.

Range: 0.000 –3000  $\mu$ S

5.3.1.1.1.45 *Delay:* Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.

Range: 0–28'800 Sec

**5.3.1.1.2 Cond. 2 (cc)**

5.3.1.1.2.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E003, is displayed in the message list.

Range: 0.000 –3000  $\mu$ S

5.3.1.1.2.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay is activated and E004 is displayed in the message list.

Range: 0.000 –3000  $\mu$ S

5.3.1.1.2.35 *Hysteresis:* Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.

Range: 0.000 –3000  $\mu$ S

- 5.3.1.1.2.45 *Delay:* Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.  
Range: 0–28'800 Sec
- 5.3.1.1.4 pH** (if Calculations = yes)
- 5.3.1.1.4.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E033, is displayed in the message list.  
Range: 0.00–14 pH
- 5.3.1.1.4.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay is activated and E034 is displayed in the message list.  
Range: 0.00–14 pH
- 5.3.1.1.4.35 *Hysteresis:* Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.  
Range: 0.00–14 pH
- 5.3.1.1.4.45 *Delay:* Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.  
Range: 0–28'800 Sec
- 5.3.1.1.5 Ammonia** (if Calculations = yes)
- 5.3.1.1.5.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E035, is displayed in the message list.  
Range: 0.00–500 ppm
- 5.3.1.1.5.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay is activated and E036 is displayed in the message list.  
Range: 0.00–500 ppm
- 5.3.1.1.5.35 *Hysteresis:* Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.  
Range: 0.00–500 ppm
- 5.3.1.1.5.45 *Delay:* Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.  
Range: 0–28'800 Sec

**5.3.1.2 Sample Temp.**

**5.3.1.2.1 Temp. 1**

5.3.1.2.1.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E007, is displayed in the message list.

Range: 30–200 °C

5.3.1.2.1.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay is activated and E008 is displayed in the message list.

Range: -10 to + 20 °C

**5.3.1.2.2 Temp. 2**

5.3.1.2.2.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E037, is displayed in the message list.

Range: 30–200 °C

5.3.1.2.2.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay is activated and E038 is displayed in the message list.

Range: -10 to + 20 °C

**5.3.1.3 Sample Flow:** Define at which sample flow an alarm should be issued.

5.3.1.3.1 *Flow Alarm:* Program if the alarm relay should be activated if there is a flow alarm. Choose between yes or no. The flow alarm will always be indicated in the display, pending error list, saved in the message list and the logger. Available values: Yes or no

*Note: Sufficient flow is essential for a correct measurement.  
We recommend to program yes.*

5.3.1.3.2 *Alarm High:* If the measuring values rises above the programmed value E009 will be issued.

Range: 9–20 l/h

5.3.1.3.35 *Alarm Low:* If the measuring values falls below the programmed value E010 will be issued.

Range: 5–8 l/h

**5.3.1.4 Case Temp.**

5.3.1.4.1 *Alarm high:* Set the alarm high value for temperature of electronics housing. If the value rises above the programmed value E013 is issued.

Range: 30–75 °C

5.3.1.4.2 *Alarm low:* Set the alarm low value for temperature of electronics housing. If the value falls below the programmed value E014 is issued.  
 Range: -10 to +20 °C

**5.3.2 and 5.3.3 Relay 1 and 2:** The contacts can be set as normally open or normally closed with a jumper. See [Relay 1 and 2, p. 26](#).  
 The function of relay contacts 1 or 2 is defined by the user.

**Note:** *The navigation in the menu <Relay 1> and <Relay 2> is equal. For reason of simplicity only the menu numbers of Relay 1 are used in the following.*

- 1 First select the functions as:
  - Limit upper/lower
  - Control upwards/downwards
  - Timer
  - Fieldbus
- 2 Enter the necessary data depending on the selected function.  
 The same values may also be entered in menu [4.2 Relay Contacts, p. 60](#)

5.3.2.1 Function = Limit upper/lower:

When the relays are used as upper or lower limit switches, program the following:

5.3.2.20 *Parameter:* select a process value

5.3.2.300 *Setpoint:* If the measured value rises above respectively falls below the set-point, the relay is activated.

<b>Parameter</b>	<b>Range</b>
Cond. 1 (sc)	0–3000 µS
Cond.2 (cc)	0–3000 µS
Temp. 1	-25 to +270 °C
Temp. 2;	-25 to +270 °C
Difference	0–3000 µS
Sample flow	0–20 l/h
pH	0 –14 pH
Ammonia	0 –500 ppm



5.3.2.400 *Hysteresis:* within the hysteresis range, the relay does not switch. This prevents damage of relay contacts when the measured value fluctuates around the alarm value.

Parameter	Range
Cond. 1 (sc)	0–3000 µS
Cond.2 (cc)	0–3000 µS
Temp. 1	0–100 °C
Temp. 2;	0–100 °C
Difference	0–3000 µS
Sample flow	0–20 l/h
pH	0 –14 pH
Ammonia	0 –500 ppm

5.3.2.50 *Delay:* Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.  
 Range. 0–600 Sec

5.3.2.1 Function = Control upwards/downwards:

The relays may be used to drive control units such as solenoid valves, membrane dosing pumps or motor valves. When driving a motor valve both relays are needed, relay 1 to open and relay 2 to close the valve.

5.3.2.22 *Parameter:* Choose on of the following process values.

- ◆ Cond.1 (sc)
- ◆ Cond.2 (cc)
- ◆ Temp. 1
- ◆ Temp. 2
- ◆ Difference
- ◆ Sample Flow
- ◆ pH
- ◆ Ammonia

5.3.2.32 **Settings:** Choose the respective actuator:

- ◆ Time proportional
- ◆ Frequency
- ◆ Motor valve

5.3.2.32.1 Actuator = Time proportional

Examples of metering devices that are driven time proportional are solenoid valves, peristaltic pumps.

Dosing is controlled by the operating time.

5.3.2.32.20 *Cycle time*: duration of one control cycle (on/off change).

Range: 0–600 sec.

5.3.2.32.30 *Response time*: Minimal time the metering device needs to react.

Range: 0–240 sec.

**5.3.2.32.4 Control Parameters**

Range for each Parameter same as [5.2.1.43, p. 67](#)

5.3.2.32.1 Actuator = Frequency

Examples of metering devices that are pulse frequency driven are the classic membrane pumps with a potential free triggering input. Dosing is controlled by the repetition speed of dosing shots.

5.3.2.32.21 *Pulse frequency*: Max. pulses per minute the device is able to respond to. Range: 20–300/min.

**5.3.2.32.31 Control Parameters**

Range for each Parameter same as [5.2.1.43, p. 67](#)

5.3.2.32.1 Actuator = Motor valve

Dosing is controlled by the position of a motor driven mixing valve.

5.3.2.32.22 *Run time*: Time needed to open a completely closed valve

Range: 5–300 Sec.

5.3.2.32.32 *Neutral zone*: Minimal response time in % of the runtime. If the requested dosing output is smaller than the response time, no change will take place.

Range: 1–20 %

**5.3.2.32.4 Control Parameters**

Range for each Parameter same as [5.2.1.43, p. 67](#)

5.3.2.1 Function = Timer:

The relay will be activated repetitively depending on the programmed time scheme.

5.3.2.24 *Mode*: Operating mode (interval, daily, weekly)

5.3.2.340 Interval/Start time/Calendar: Dependent on options operating mode.

5.3.2.44 *Run time*: time the relay stays active.

Range: 5–32'400 Sec

- 5.3.2.54 *Delay*: during run time plus the delay time the signal and control outputs are held in the operating mode programmed below.  
Range: 0–6'000 Sec
- 5.3.2.6 *Signal Outputs*: select the behavior of the signal outputs when the relay closes. Available values: cont., hold, off
- 5.3.2.7 *Output/Control*: select the behavior of the control outputs when the relay closes. Available values: cont., hold, off
- 5.3.2.1 **Function = Fieldbus:**
- The relay will be switched via the Profibus input. No further parameters are needed.
- 5.3.4 Input:** The functions of the relays and signal outputs can be defined depending on the position of the input contact, i.e. no function, closed or open.
- 5.3.4.1 *Active*: Define when the input should be active:
- No: Input is never active.  
When closed: Input is active if the input relay is closed  
When open: Input is active if the input relay is open
- 5.3.4.2 *Signal Outputs*: Select the operation mode of the signal outputs when the relay is active:
- Continuous: Signal outputs continue to issue the measured value.  
Hold: Signal outputs issue the last valid measured value. Measurement is interrupted. Errors, except fatal errors, are not issued.  
Off: Set to 0 or 4 mA respectively. Errors, except fatal errors, are not issued.
- 5.3.4.3 *Output/Control*: (relay or signal output):
- Continuous: Controller continues normally.  
Hold: Controller continues on the last valid value.  
Off: Controller is switched off.

- 5.3.4.4 *Fault:*
- |     |   |
|-----|---|
| No: | No message is issued in pending error list and the alarm relay does not close when input is active. Message E024 is stored in the message list. |
| Yes | Message E024 is issued and stored in the message list. The Alarm relay closes when input is active.   |
- 5.3.4.5 *Delay:* Time which the instrument waits, after the input is deactivated, before returning to normal operation.  
Range: 0–6'000 Sec

## 5.4 Miscellaneous

- 5.4.1 *Language:* Set the desired language.  
Available settings: German /English/French/Spanish/Italian
- 5.4.2 *Set defaults:* Reset the instrument to factory default values in three different ways:
- ◆ **Calibration:** Sets calibration values back to default. All other values are kept in memory.
  - ◆ **In parts:** Communication parameters are kept in memory. All other values are set back to default values.
  - ◆ **Completely:** Sets back all values including communication parameters.
- 5.4.3 *Load Firmware:* Firmware updates should be done by instructed service personnel only.
- 5.4.4 **Password:** Select a password different from 0000 to prevent unauthorized access to the menus "Messages", "Maintenance", "Operation" and "Installation".  
Each menu may be protected by a *different* password.  
If you forgot the passwords, contact the closest SWAN representative.
- 5.4.5 *Sample ID:* Identify the process value with any meaning full text, such as KKS number.
- 5.4.6 *Line Break Detection:* Define if message E028 should be issued in case of a line break on signal output 1 or 2.  
Choose between <Yes> or <No>.

## 5.5 Interface

Select one of the following communication protocols. Depending on your selection, different parameters must be defined.

**5.5.1 Protocol: Profibus**

- 5.5.20 Device address: Range: 0–126
- 5.5.30 ID No.: Range: Analyzer; Manufacturer; Multivariable
- 5.5.40 Local operation: Range: Enabled, Disabled

**5.5.1 Protocol: Modbus RTU**

- 5.5.21 Device address: Range: 0–126
- 5.5.31 Baud Rate: Range: 1200–115 200 Baud
- 5.5.41 Parity: Range: none, even, odd

**5.5.1 Protocol: USB stick**

Only visible if a USB interface is installed. No further settings are possible.

**5.5.1 Protocol: HART**

- 5.5.24 Device address: Range: 0–63

## 10. Material Safety Data Sheets

### 10.1. Swan Cation Exchanger Resin

Product name: Cation Exchange Resin  
Catalogue number: A-82.841.030 and A-82.841.031

**Download  
MSDS** The current Material Safety Data Sheets (MSDS) for the above listed Reagents are available for downloading at [www.swan.ch](http://www.swan.ch).

## 11. Default Values

**Operation:**

Sensors:	Filter Time Const.:.....	20 s
	Hold after Cal.:.....	0 s
Relay Contacts	Alarm Relay .....	same as in Installation
	Relay 1/2 .....	same as in Installation
	Input.....	same as in Installation
Logger:	Logger Interval:.....	30 min
	Clear Logger: .....	no
Display:	Screen 1 and 2; Row 1: .....	Cond 1(sc)
	Screen 1 and 2; Row 2: .....	Cond 2(cc)
	Screen 1 and 2; Row 3: .....	None

**Installation:**

Sensors	Miscellaneous; Calculations: .....	no
	Miscellaneous; Meas. unit .....	$\mu\text{S/cm}$
	Miscellaneous; Monitoring of resin .....	no
	Miscellaneous; Resin Capacity:.....	1.8
	Miscellaneous; Volume of resin: .....	1.0 l
	Sensor Parameters; Sensor 1 and 2;Cell Constant.....	$0.0415 \text{ cm}^{-1}$
	Sensor Parameters; Sensor 1 and 2; Temp. corr.....	$0.00 \text{ }^\circ\text{C}$
	Sensor Parameters; Sensor 1 and 2; Cable length .....	0.0 m
	Sensor Parameters; Sensor 1; Temp. comp.; Comp: .....	Ammonia
	Sensor Parameters; Sensor 2; Temp. comp.; Comp: .....	Strong Acids
	Flow: .....	yes
Signal Output 1	Parameter: .....	Cond 1(sc)
	Current loop: .....	4 –20 mA
	Function: .....	linear
	Scaling: Range low: .....	0.000 $\mu\text{S}$
	Scaling: Range high:.....	1000.00 $\mu\text{S}$
Signal Output 2	Parameter: .....	Cond 2(cc)
	Current loop: .....	4 –20 mA
	Function: .....	linear
	Scaling: Range low: .....	0.000 $\mu\text{S}$
	Scaling: Range high:.....	1000.00 $\mu\text{S}$
Alarm Relay:	Conductivity; Cond. 1 (sc) and Cond. 2 (cc):	
	Alarm high:.....	3000.00 $\mu\text{S}$
	Alarm low: .....	0.000 $\mu\text{S}$
	Hysteresis: .....	10.0 $\mu\text{S}$
	Delay:.....	5 s

Sample Temp: (Temp. 1 and Temp. 2)

Alarm High: ..... 160 °C

Alarm Low: ..... 0 °C

Sample Flow:

Flow Alarm ..... yes

Alarm high: ..... 16 l/h

Alarm low: ..... 5 l/h

Case temp. high: ..... 65 °C

Case temp. low: ..... 0 °C

Relay 1/2

Function: ..... limit upper

Parameter: ..... Cond 1(sc)

Setpoint: ..... 1000 µS

Hysteresis: ..... 10 µS

Delay: ..... 30 s

**If Function = Control upw. or dnw:**

Parameter: ..... Cond 1(sc)

..... Settings: Actuator: Frequency

..... Settings: Pulse Frequency: 120/min

..... Settings: Control Parameters: Setpoint: 1000 µS

..... Settings: Control Parameters: P-band: 10 µS

..... Settings: Control Parameters: Reset time: 0 s

..... Settings: Control Parameters: Derivative Time: 0 s

..... Settings: Control Parameters: Control Timeout: 0 min

Settings: Actuator ..... Time prop.

..... Cycle time: 60 s

..... Response time: 10 s

Settings: Actuator ..... Motor valve

..... Run time: 60 s

..... Neutral zone: 5%

**If Function = Timer:**

Mode: ..... Interval

..... Interval: 1 min

Mode: ..... daily

..... Starting time: 00.00.00

Mode: ..... weekly

..... Starting time: 00.00.00

..... Calendar; Monday to Sundayoff

Run time: ..... 10 s

Delay: ..... 5 s

Signal output: ..... cont.

Output/Control: ..... cont.



---

Input:	Active .....	when closed
	Signal Outputs .....	hold
	Output/Control .....	off
	Fault.....	no
	Delay.....	10 s
Miscellaneous	Language: .....	English
	Set default:.....	no
	Load firmware:.....	no
	Password: .....	for all modes 0000
	Sample ID: .....	- - - - -
	Line break detection .....	no

## 12. Index

<b>A</b>			
Alarm Relay . . . . .	11, 25	Profibus . . . . .	29
Application . . . . .	10	USB . . . . .	30
Application Range . . . . .	10		
<b>C</b>		<b>M</b>	
Cable thicknesses . . . . .	21	Measuring principle . . . . .	11
Cation Conductivity . . . . .	11	Modbus . . . . .	29
cell constant . . . . .	11	Mounting	
Changing values . . . . .	36	Instrument panel . . . . .	18
Checklist . . . . .	17	Mounting requirements . . . . .	18
Cleaning		<b>O</b>	
Sensor . . . . .	38	On site requirements . . . . .	17
Current outputs . . . . .	28		
<b>D</b>		<b>P</b>	
Deaeration tube . . . . .	44	Power Supply . . . . .	24
Default Values . . . . .	79	Pre-rinse Option . . . . .	12
		Pre-rinse set-up . . . . .	20
<b>E</b>		Profibus . . . . .	30
Error List . . . . .	47		
Exhausted resin . . . . .	39	<b>R</b>	
<b>F</b>		Reagent consumption . . . . .	37
Fluidics . . . . .	13	Relays . . . . .	10
		Requirements, on-site . . . . .	14
<b>H</b>		Run-in period . . . . .	17
HART . . . . .	30		
<b>I</b>		<b>S</b>	
inlet filter . . . . .	42	Safety Features . . . . .	11
Input . . . . .	11, 25	Sample requirements . . . . .	14
Instrument Overview . . . . .	16	Sensor parameters . . . . .	31
Interface . . . . .	11, 28	Setup . . . . .	31
HART . . . . .	30	Signal Outputs . . . . .	10, 28
Modbus . . . . .	29	slot lock system . . . . .	38
		Software . . . . .	35
		Specific Conductivity . . . . .	11
		Standard . . . . .	12
		Standard Temperature . . . . .	12
		System, Description of . . . . .	10

**T**

Technical Data . . . . . 16  
Temperature compensation . . . . . 12  
Terminals . . . . . 23, 25–26, 29

**U**

USB Interface . . . . . 30

**W**

Wire . . . . . 21





Swan Products - Analytical Instruments for:



**Swan** is represented worldwide by subsidiary companies and distributors and cooperates with independent representatives all over the world. For contact information, please scan the QR code.

Swan Analytical Instruments · CH-8340 Hinwil  
[www.swan.ch](http://www.swan.ch) · [swan@swan.ch](mailto:swan@swan.ch)

**SWISS  MADE**

